



Pressure Loss

Perda de pressão Druk Verlies Druckverluste Partes de charge
 Tabela Predite di Carico Pérdidas de Carga Απώλεια Πίεσης Basınç Kaybı

		METRIC							
		100PSGA		150PSGA		200PSGA		250PSGA	
gpm	Angle 1"	Globe 1"	Angle 1 1/2"	Globe 1 1/2"	Angle 2"	Globe 2"	Angle 2 1/2"	PSI	PSI
2	4.1	4.1	-	-	-	-	-	0.5	0.14
5	4.9	4.6	-	-	-	-	-	1	0.28
10	5.8	5.1	-	-	-	-	-	2	0.56
20	5.3	4.5	-	-	-	-	-	3	0.83
30	5.0	4.5	2.1	1.6	-	-	-	4	1.11
40	8.5	7.4	2.6	2.2	1.9	2.0	-	5	1.39
50	-	-	4.8	2.9	2.0	1.6	-	6	1.67
75	-	-	11.1	7.4	2.7	1.9	-	7	1.94
100	-	-	18.8	12.7	4.6	3.4	-	8	2.22
125	-	-	-	-	8.1	5.1	-	9	2.50
150	-	-	-	-	11.5	7.3	-	10	2.78
								12	3.33
								14	3.89
								15	4.40
								22	6.10
								28	7.80
								34	9.44



Rain Bird Corporation
 Contractor Division
 970 West Sierra Madre Avenue
 Azusa, CA 91702
 Phone: (626) 963-9311
 Fax: (626) 812-3411

Rain Bird Technical Services
 (800) 247-3782 (U.S. only)

Rain Bird Corporation
 Commercial Division
 6991 East Southpoint Road
 Tucson, AZ 85706
 Phone: (520) 741-6100
 Fax: (520) 741-6522

Specification Hotline
 (800) 458-3005 (U.S. only)

Rain Bird International, Inc.
 145 North Grand Avenue
 Glendora, CA 91741 USA
 Phone: (626) 963-9311
 Fax: (626) 963-4287
www.rainbird.com

© Registered trademark of Rain Bird Corporation
 © 2007 Rain Bird Corporation - 402

Rain Bird. Conserving more than water.

P/N 210594



PGA Valve Installation and Operation Instructions Troubleshooting Guide

Válvulas PGA
 Manual de instalación y funcionamiento
 Localización de averías

Elektromagnetventile PGA
 Installations- und Bedienungsanleitung
 Fehlersuche / Fehlerbehebung

Válvula PGA
 Instruções de Instalação e Operação
 Guia de resolução de problemas

PGA Klapp
 Instructies voor installatie en bediening
 Gids voor probleemoplossing

Valvole Serie PGA
 Installazione ed istruzioni operative
 Guida alle problematiche

ΒΑΝΑ ΣΕΙΡΑ: PGA
 Οδηγός Εγκατάστασης και Λειτουργίας
 Οδηγός για επίλυση πιθανών προβλημάτων

Electrovanne PGA
 Instructions d'installation et d'utilisation

PGA VANA
 Tesisat ve Kullanım Kılavuzu
 Sorun Giderme Kılavuzu

